PET919 - Rechargeable Remote Dog Trainer with Soft Contact Probes

User Manual

Model M919 - Technical Specifications:

4 Training Modes: Shock/Vibration/Beep/Tracking Light Receiver with Auto Sleep Mode and Remote Activation 100 adjustable levels of Vibration & Shock Receiver with non-metallic contact points Collar size: good for Small & Large dogs Rechargeable & Waterproof Range up to 1000 yards

Package:

1 x Remote Transmitter 1 x Receiver Collar* 1 x Collar Strap* 1 x USB Cable 1 x Charger 1 x User Manual 1 x Test Light

*Dual version M919-2 comes with 2 collars

Pet919 Premium Dog Training Collar, Models M919-1/M919-2 What is in the Package:



M919-1/M919-2 • Remote Transmitter • Receiver Collar / E-Collar Radio Frequency: 900 Mhz Built-in Batteries information: Transmitter: 3.7V 500mA Li-ion Receiver: 3.7V 500mA Li-ion



Receiver Contact Points





Testing Light Kit

Charger and USB Cable

 Intensity Level - indicates the intensity level of Static Shock and Vibration in the range from 0-100.
 Beep/Tone Indicator - flashes when beep is sent.

3. Static Shock Button - press the button to deliver Static Shock to the collar. Hold it down for continuous shock delivery - it will stop automatically after 10 seconds to avoid injury.

4. Tone/Beep Button - press the button to send an audible tone/beep to the receiver collar. When your dog is well trained, the tone button is all you need to effectively interact with dog.

5. Channel Switch/Tracking Light - the remote has 3 channels that allow you to work with up to 3 dogs. Press the button to switch between channel 1-3. Please refer to Synchronizing Remote Transmitter with Receiver Collar paragraph to learn how you can reprogram the system to work with 1-3 collars. Tracking Light - If you press and hold the button for 3 seconds it will turn on/off the Receiver Tracking Light, so you can track your dog in the dark.

6. Level UP "+"- press the button to increase the level of intensity by 1 point. Hold it down for a faster change.

7. Charging Port - use it to recharge the remote.

8. Level Down "-" - press the button to decrease the level of inte Hold it down for a faster change.

9. Vibration Button - press the button to deliver Vibration stimulation to your dog. Hold it down for continuous vibration - it will stop automatically after 10 second to avoid injury.

10. Channel Indicator - shows the channel number that has been selected.

11. Battery Charge Indicator - recharge the remote when it shows a low level.



7

FEATURES

1. 4 Training Modes: Static Shock, Vibration, Tone, and Tracking Light.

2. Rechargeable Transmitter and Receiver - recharge time is about 3-4 hours.

3. Fully waterproof Receiver Collar.

4. The system communication range is up to 1000 yards (in ideal conditions).

5. 100 levels of Static Shock and Vibration Stimulation - makes it perfect for all breeds.

6. The remote can be used with up to 3 collars which allows you to control up to 3 dogs.

7. Power saving design with Auto Sleep Mode and Remote Activation: the receiver collar will go to Sleeping Mode after 5 minutes of being inactive - send any command from remote to wake it up.

8. Non-metallic conductive contact points specifically designed to avoid skin irritation.

HOW DOES PET919 DOG TRAINING SYSTEM WORK?

Pet919 Dog Training System can assist you with controlling and training your dog without a leash in the range up to 1000 yards. Using a Remote Transmitter you can send a signal to the collar in form of Static Shock, Vibration, or Tone. By using Pet919 Dog Training System consistently, you can train your dog to eliminate any undesired behavior (jumping up, digging, chasing, etc.) and teach your dog many obedience commands (sit, come, stay, etc).

IMPORTANT NOTES

•The Remote System range goes up to 1000 yards. Hold the Transmitter horizontally and away from your body to achieve maximum range. Weather condition, terrain, vegetation, and interference from other electronic devices can affect the maximum communication distance of the system.

•There are 100 levels of Static Shock and Vibration Simulation. If you use the strongest level there is a chance that it can penetrate dog's fur up to 6mm thick. Do not shave your Dog's neck to reduce the risk of skin irritation.

•For comfort, safety, and effectiveness of the system, please start training your pet with the lowest Static Shock level. It's fine to have a Vibration level on medium or high. Please check your dog's neck after each training session for skin irritation. If skin irritation develops, discontinue to use the collar for 48 hours. If condition persist beyond 48 hours, please consult your veterinarian.

Do not attach a leash to the collar. Use a separate collar if there is a need for a leash.
We suggest you to use the Vibration Stimulation first before starting to use the Static Shock. Then slowly start training with the lowest level of Static Shock Stimulation. If you follow this training method, your dog will learn that Static Shock Stimulation will come after Vibration. Hence, the Vibration alone can effectively cure unwanted behavior of your dog without a need for Static Shock.

PREPARING REMOTE TRANSMITTER FOR YOUR FIRST USE:

Make sure that Remote Transmitter is charged before proceeding to the training: 1. The charging port is located at the bottom of remote. Carefully insert the charging cable into the charging port.

2. The Battery Charge Indicator will start flashing. It takes about 3-4 hours to get a full charge.

3. The remote transmitter is not waterproofed - keep it in a dry place!

REMOTE TRANSMITTER OPERATION

1. The remote always stays in the Stand-by Mode. Simply press any button to wake it up.

2. If you have 2 or 3 collars, you can select which collar is being controlled (1, 2, 3) by pressing the Channel Switch Button.

3. Press the Vibration Button to deliver Vibration Stimulation to your dog.

4. Press the Static Shock Button to deliver Static Shock to your dog.

5. Press the Tone/Beep Button to deliver beeping tone to your dog.

6. You are welcome to attach a lanyard for your convenience.



PREPARING RECEIVER COLLAR FOR YOUR FIRST USE:

Make sure that Receiver Collar is charged before proceeding to the training:

1. Carefully open the rubber cover over the charging port and connect the charger.

2. Red LED light will start flashing to indicate that receiver is charging.

3. Red LED indicator will stop flashing and turn solid red when collar is fully charged. It takes about 2-4 hours.

4. Put the rubber cover back over the charging port to ensure collar is fully waterproof.

RECEIVER COLLAR OPERATION

1. When Receiver is charged and turned on, it always stays in the Standby Mode waiting for any command to activate it. Red flashing LED indicates that receiver is active.

2. If receiver is charged and turned on but it still does not respond to any command from remote - it has to be re-synchronized.

SYNCHRONIZING REMOTE TRANSMITTER WITH RECEIVER COLLAR

Sometimes the collar can loose connectivity with remote. The fix is pretty quick and simple. Follow these steps to re-synchronize the system:

1. Make sure that both the Transmitter and Receiver are fully charged and turned on. 2. Press and hold the Power button on the Receiver Collar for about 5 seconds to enter the Synchronization Mode - the receiver will beep first and right after that red LED will start flashing.

3. While red LED is flashing, send any correction command from remote. We rec-ommend you to send a Vibration command by pressing and holding the Vibration button on remote until you feel that collar is vibrating. If no command is sent, the flashing will stop after 15 seconds.

4. The system is now resynchronized - try to send any command to test it. If you have 2 or 3 collars, repeat this steps for all collars on channels 1, 2 and 3.



Charging Port



Power On/Off (1 press) Re-sync (hold for 5 seconds)

TESTING PETSPY DOG TRAINING SYSTEM

Static Shock Test:

•Take the included Test Light Kit and put its metal wire on the Receiver Collar's Contact Points.

•Press the Static Shock Button on the Remote Transmitter.

•The Test Light will light up indicating that Shock is working.

•The higher the Shock level is the brighter it should be.

Vibration Test:

•Press the Vibration Button on the Remote Transmitter.

•The Receiver Collar will vibrate indicating that Vibration Stimulation is working.

•Try to adjust the level of vibration and see how the intensity is changing.

Receiver Tone/Beep Test:

•Press the Receiver Tone Button on the Remote Transmitter.

•The Receiver Collar will beep indicating that Receiver Tone is working.

COLLAR FITTING:

CAUTION: proper fitting and placement of the Dog Training Collar is important for effective training. The collar must fit your dog securely, but loose enough to allow one finger space between the collar and your dog's neck. The Contact Points must have direct contact with your pet's skin on the underside of dog's neck.

Putting the Collar On:

1. Have your dog standing comfortably.

2. Center the Contact Points beneath the dog's neck and touching the skin.

3. The Collar should fit securely, yet loose enough to allow one finger space between the collar and dog's neck.

4. Allow your dog to wear the collar for several minutes and check the fitment again when your dog becomes more comfortable wearing the collar.

FIND THE BEST STIMULATION LEVEL FOR YOUR DOG

CAUTION: Start with Vibration mode and use Static Shock only as a last resort. PetSpy e-collar is a powerful tool for encouraging desired dog's behavior. But first, you must identify an e-collar intensity setting for your dog - it has to be high enough to be noticed, but not so high as to be disruptive. Your dog must learn to act in response to the e-collar stimulation and understand that he can control it by his actions.



You will find this method of e-collar training is even gentler than many traditional leash-training methods. Additionally, the e-collar improves communication by providing instant feedback to your dog during the training. This reduces confu- sion, fosters a positive training attitude, and accelerates learning, rapidly producing off-leash reliability.

Even if your dog already knows the basic obedience commands, follow the procedures given. Your dog must learn how to respond to the e-collar for each command before you can use your Pet919 collar for training at a distance. Pet919 Premium

Dog Training Collar has 100 different stimulation levels. This allows you to choose the level that is best for your pet. Once you have placed the Receiver Collar on your pet, it is time to find the Stimulation Level that is best for him. This is called the *Recognition Level*. A slight change in your pet's behavior, such as looking around in curiosity, scratching at his collar, or flicking his ears, indicates the Recognition Level that is best for him.

Follow the steps below to find your dog's Recognition Level:

1. Starting at the Lowest Level of stimulation on the Remote (1-20), press the Vibration or Shock Stimulation Button continuously.

2. If your pet shows no reaction, repeat the Stimulation Level several times before moving up to the next level.

CAUTION: YOUR DOG SHOULD NOT BARK OR PANIC WHEN RECEIVING STIMULATION. IF THIS HAPPENS, THE STIMULATION LEVEL IS TOO HIGH AND YOU NEED TO GO BACK TO THE PREVIOUS LEVEL AND REPEAT THE PROCESS.

3. Move up through the Stimulation Levels until your dog reliably responds to the stimulation.

4. If your dog continues to show no response at the Highest Level, check the fit of the Receiver Collar. If your dog has long or thick fur you might have to trim it just a little bit around the neck. Then go back to step 1 and repeat the process. If this still does not yield any results, test the collar to insure it's working properly.

Please refer to PetSpy Dog Training Guide E-Book for more dog training tips. If

for some reason you don't have it - just visit our website *www.petspystore.com* to download it - it is free!

GENERAL TIPS

• PetSpy Dog Training Collar is not design to be worn constantly. We recommend you to limit collar usage just during the active Training Sessions. Always take off the collar when you leave your dog unattended.

• Most dogs will feel uncomfortable when wearing collar for the first time. Don't use any commands until your dog has gotten used to the collar which will normally take several days.

• Eliminate one unwanted action or teach one obedience command at a time. If you move to quickly with training, your dog may become confused.

• Be consistent in your training. Give your dog the same stimulation for each unwanted action. We suggest you to use Vibration Stimulation before starting the Static Shock Stimulation. If you follow this training method, your dog will learn that Static Shock Stimulation might come after Vibration. Hence, the Vibration Stimulation alone can effectively cure unwanted behavior of your dog.

• Do not over-correct. Use as few stimulation as possible to train your dog.

• Following a predefined scenario in all Training Sessions can dramatically improve your chances of success.

• Should your dog react to the training by hiding or reacting fearfully, redirect his attention to a simple command such as "Speak" or "Sit" to calm him down. Use treats to help your dog understand which commands have been done correctly.

TROUBLESHOOTING

My Pet919 Dog Training Collar is not working?

•Make sure that both the Remote Transmitter and Receiver Collar are fully charged.

•Please follow the steps from *Synchronizing Remote Transmitter with Receiver Collar* paragraph to make sure that transmitter is in sync with collar.

CAUTION: While the Receiver Collar is waterproof, the Remote Transmitter is not and must be kept in a dry place! Water can irreversibly damage the Remote Transmitter!

REGULAR MAINTENANCE AND STORAGE

•When not used, the remote Dog Training System must be kept in a dry place just like any other electronic device.

•To prevent batteries from damage, charge both the Transmitter and Receiver regularly even when it's not used. Make sure you do not charge it for longer than 4 hours.

•Clean the receiver and contact points weekly.

•Check your dog's neck for irritation weekly.